


\*Front Case Assembly includes speaker, orange top button and display lense on applicable models



Tier 1



Tier 2



Tier 3

## KNG Portable Parts Lists

### Front Assembly

Ref #	Part #	Description
1	7011-31006-901	Assembly, Front, Tier 2
1	7011-30994-503	Assembly, Front, Tier 3
1	NA	Assembly, Front, Tier 1
2	2509-30990-500	Inlay, P150
2	2509-30990-501	Inlay, P400
2	2509-30990-502	Inlay, P500
2	2509-30990-503	Inlay, P800
3	2003-30964-302	LCD P150
3	2003-30964-301	LCD - P400/P500/P800
5	NA	Assembly, Systems Board
6	2509-30985-900	Inlay, Collar
7	2513-30992-200	Inlay, Toggle-Switch – obsolete
8	Inc. in Item 1	Speaker, 40mm, 8 Ohm
9	1700-60284-200	Flex Circuit
10	1411-40001-800	Foam Mic Gasket molded with mic
11	1411-40001-800	Bushing, Mic – see previous pn
12	1310-20000-500	Mic ELEMENT
13	2800-31000-500	Mic Spacer